



1594 PLANER

Pos.	Part Number	Description {Qty.}	F/C	Pos.	Part Number	Description {Qty.}	F/C
2	2 604 220 479	Field 120V	22	44	2 603 320 004	Nut {2}	89
3	2 604 011 284	Armature w/Fan 120V	AW	46	2 609 110 063	Plate	88
4	1 607 200 158	Switch	15	47	2 601 254 000	Clip	9
5/1	1 900 452 012	Terminal Sleeve {2}	10	49	2 609 100 022	Cover	74
6	2 600 703 018	Strain Relief	11	57	2 604 448 181	Cable 233mm	10
7	2 601 035 001	Cord Clamp	89	58	2 604 448 118	Cable 213mm	10
8	2 609 130 369	Nameplate	9	60	2 609 100 148	Tube	9
9	2 609 130 203	Label	9	71	2 609 110 064	Clamp {2}	80
11	2 910 611 019	Screw {2}	89	74	2 608 635 405	Blade Set (PA1202)	94
15	2 609 130 372	Label	9	75	2 602 316 001	Guide {2}	80
16	2 604 449 055	Brush Holder {2}	25	76	2 609 110 107	Holder {2}	80
17	2 609 100 087	Brush Cap {2}	64	80	2 609 100 088	Foot	9
19	2 912 401 420	Screw {14}	89	81	2 609 110 109	Spring	27
20	2 609 110 155	Screw	89	201	2 603 433 001	Screw {4}	89
26	2 609 110 131	Nut	89	202	2 916 069 088	Washer {4}	65
28	2 609 110 060	Pulley	36	203	2 609 110 084	Screw {6}	89
29	2 609 110 061	Pulley	48	654	2 607 950 025	Wrench	9
30	2 609 100 139	Handle	74	801	2 609 100 141	Housing Assembly	71
31	2 609 100 029	Belt	50	805	3 604 460 555	Cord	11
32	2 609 100 024	Cover	70	810	2 609 120 064	Brush Set	26
33	2 609 110 077	Spring	27	813	1 610 905 025	Ball Bearing {2}	61
35	2 609 100 023	Cover	70	814	3 600 900 514	Ball Bearing	60
37	2 609 100 140	Cap	74	825	2 609 110 175	Housing Assembly	73
38	2 609 110 162	Dial	63			w/pos. 814, 855	
40	2 609 100 028	Baffle	24	855	2 600 905 064	Ball Bearing	51
41	2 601 329 053	Spring Clip	27	870	2 609 110 161	Drum Assembly	48
43	2 917 800 053	Roll Pin	66			w/pos. 71 - 76, 201 - 203	

Service Notes:

+ = Not Illustrated

* = As Required

F/C = Failure Code

AW = Refer to AW Labor Time Chart